

AISC Live Webinars

Thank you for joining our live webinar today.
We will begin shortly. Please standby.

Thank you.

Need Help?
Call ReadyTalk Support: 800.843.9166

Design of Façade Attachments

Session L1: Façade Attachments, Part 1
May 9, 2019



AISC Live Webinars

Today's live webinar will begin shortly. Please stand by.

As a reminder, all lines have been muted. Please type any questions or comments through the chat feature on the left portion of your screen.

Today's audio will be broadcast through the internet.
Alternatively, to hear the audio through the phone, dial:

(800)-581-5838
Passcode: 959842



AISC Live Webinars

Audio Options

Today's audio will be broadcast through the internet.

Alternatively, to hear the audio through the phone, dial:

(800)-581-5838
Passcode: 959842



AISC Live Webinars

AIA Credit

AISC is a Registered Provider with The American Institute of Architects Continuing Education Systems (AIA/CES). Credit(s) earned on completion of this program will be reported to AIA/CES for AIA members. Certificates of Completion for both AIA members and non-AIA members are available upon request.

This program is registered with AIA/CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.

Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.



AISC Live Webinars

Copyright Materials

This presentation is protected by US and International Copyright laws. Reproduction, distribution, display and use of the presentation without written permission of AISC is prohibited.

© The American Institute of Steel Construction 2019

The information presented herein is based on recognized engineering principles and is for general information only. While it is believed to be accurate, this information should not be applied to any specific application without competent professional examination and verification by a licensed professional engineer. Anyone making use of this information assumes all liability arising from such use.



AISC Live Webinars

Course Description

Façade Attachments, Part 1
May 9, 2019

Every type of facade system presents its own challenges for the design team. Where and how are the gravity and lateral loads supported? How much movement can the facade system accommodate? What is the jointing pattern? In this session, we will explore masonry cavity wall systems, aluminum-glass curtain wall systems and panelized systems such as precast concrete panels or prefabricated metal-framed panels with masonry or glass-fiber reinforced concrete facing to help answer these questions.



AISC Live Webinars

Learning Objectives

- List the issues to consider when locating joints in masonry cavity walls.
- Describe how panelized façade systems are best supported.
- Explain the importance of allowing for field adjustments of aluminum curtain walls.
- Name the sources of vertical movement in façade systems.



Design of Façade Attachments

Session L1: Façade Attachments, Part 1

May 9, 2019



Alec Zimmer, PE
Senior Project Manager
Simpson Gumpertz & Heger Inc.
Waltham, MA



Syllabus for Webinar Series Sessions

- Session R1
 - Fundamentals of Facades
 - Design Criteria
 - Design and Execution Responsibilities
 - Thermal Bridging
 - Planning for Clearances
 - Accommodating Tolerances
- Session L1
- Session L2
- Session L3



9

Syllabus for Webinar Series Sessions

- Session R1
- Session L1
 - Traditional Masonry Cavity Walls
 - Panelized Façade Systems
 - Aluminum-Glass Curtain Walls
 - Sizing Joints for Vertical Movement
- Session L2
- Session L3



10

Masonry Cavity Walls

Masonry Cavity Walls




The strategy for supporting masonry cavity walls starts with the decision for the location of the horizontal movement joints.


11

Masonry Cavity Walls

General Description



NOTES:

- ① Veneer.
- ② Veneer anchor.
- ③ Exterior sheathing, usually gypsum based.
- ④ Water barrier.
- ⑤ Insulation.
- ⑥ Through wall flashing.
- ⑦ Shelf angle.
- ⑧ Backup wall (metal stud shown).
- ⑨ Top of backup wall connection allows vertical movement between portion of wall above soft joint and portion below, plus allow in-plane movement.
- ⑩ Soft joint under shelf angle.


12

Masonry Cavity Walls




The top-left image shows blue insulation blocks placed in the cavity between two rows of concrete masonry units. The top-right image shows a brick cavity filled with mortar and rubble. The bottom-left image is a close-up of a metal tie connecting two masonry units. The bottom-right image shows a brick wall with a metal tie connecting to a blue insulation panel.



13

Masonry Cavity Walls

Volume Change



The top-left image shows a vertical crack in a brick wall. The bottom-left image shows a vertical crack in a brick wall. The right image shows a diagonal crack in a brick wall, likely due to volume change.



14

Masonry Cavity Walls

Movement Joints

15

Masonry Cavity Walls

Punched Window Openings Horizontal Joint at Window Head

NOTES:

- 1 Soft joint below shelf angle.
- 2 Movement joint between shelf angle assembly and backup wall below. The connection to underside of shelf angle assembly provides out-of-plane lateral support to the backup wall.
- 3 Movement joint between shelf angle assembly and window head. The window head connection provides out-of-plane support of the window.
- 4 Backup wall of block or metal studs below movement joint is supported on floor slab.
- 5 Backup wall above movement joint is supported on shelf angle assembly and anchored to underside of floor slab.
- 6 Hangers from plate brackets support the shelf angle assembly.
- 7 Roll beams or kickers can resist the twist of the spandrel beam.


16

Masonry Cavity Walls

Strip Windows



Elevation



Strip Window

Metal Stud Backup

Cavity Wall (Membrane, Insulation, and Flashing Not Shown for Clarity)

NOTES:

- ① Strip window. The shelf angle is at the window head.
- ② Movement joint between shelf angle assembly and window head. The window head connection provides out-of-plane support of the window.
- ③ Metal stud backup wall is supported off of the hung shelf angle assembly. Studs are connected to the edge of the slab and cantilever up to provide vertical and out-of-plane support at the sill of the strip window.
- ④ At the roof, the metal studs cantilever up past the slab edge to form the parapet.
- ⑤ Kickers or roll beams can resist the twist of the spandrel beam.
- ⑥ The finish ceiling location may dictate the location of the kickers.
- ⑦ Lateral tie to slab so studs can cantilever by edge of slab up to sill of window for out-of-plane support of window.




17

Masonry Cavity Walls

Parameters Affecting Design

- Architecture Decisions
 - Fenestration
 - Horizontal Joint Patterns
 - Vertical Joint Patterns
- Dimensions
 - Story Heights
- Magnitude of Loads
- Field Adjustability
- Relative Movements
- Durability
- Thermal Performance






18

Masonry Cavity Walls

Architectural Decisions

Ceilings, MEP



The diagram shows a cross-section of a masonry cavity wall. A horizontal ceiling slab is supported by a steel beam. Below the ceiling, there are two circular MEP components, one blue and one red. A hand is pointing to the blue component. A light blue rectangular panel is also shown. A hand is pointing to the bottom of this panel. The masonry wall is shown on the right, with a vertical cavity. The ceiling slab is supported by a steel beam that is attached to the masonry wall.



19

Masonry Cavity Walls


Architectural Decisions

Vertical Control Joints

(a)

(b)

(c)



The diagrams show three different ways to handle vertical control joints in a masonry wall. (a) shows a wall with a vertical control joint and a horizontal control joint. (b) shows a wall with a vertical control joint and a horizontal control joint, with a hand pointing to the joint. (c) shows a wall with a vertical control joint and a horizontal control joint, with a hand pointing to the joint.



20

Masonry Cavity Walls

Dimensions

NOTES:

- ① Shelf angle made from standard rolled angle shape.
- ② Structural spacer may be required for projects with thick insulation requirements in the cavity or with thick veneer in order to keep standard rolled angle as shelf.
- ③ Line of membrane and flashing.
- ④ A minimum of 2/3 of the veneer should bear on the shelf angle.
- ⑤ Continuous plate to support backup wall above.
- ⑥ Structural hangers behind membrane and within the thickness of the backup wall.

21

Masonry Cavity Walls

Dimensions

Thickness of Backup

Relative Location of Column

22

Masonry Cavity Walls

Field Adjustability

- Slab edge
- Backup wall
- Shelf angle

The diagram illustrates a cross-section of a masonry cavity wall. On the left, a concrete slab edge is shown. To its right is a backup wall. A shelf angle is attached to the backup wall and extends to the exterior masonry face. The exterior masonry is shown in a yellowish-brown color, and the interior masonry is in a reddish-brown color. The shelf angle is a red L-shaped component.



23

Masonry Cavity Walls

Vertical Movements

The diagram shows four components of vertical movements, each in a box, separated by plus signs. From left to right: Spandrel Deflection (a curved red line), Spandrel Rotation (a diagram of a spandrel with rotation angles θ_{top} and θ_{bot} and horizontal displacements Δ_{sh} and Δ_{sb}), Shelf Angle Rotation (an L-shaped red component), and Brick Volume Change (a brick with a vertical dimension $h = \text{story ht.}$ and a horizontal dimension $ke h + \alpha \Delta_T h$). Below these is a large equals sign leading to a box labeled "Design Vertical Movements".

Note: Column shortening is important too for tall building's bottom story.



24

Masonry Cavity Walls

Joint Compressibility

$\pm 30\% J$

J



25

Masonry Cavity Walls

In-Plane Movements

Seismic or Wind Drift



26

Masonry Cavity Walls

In-Plane Movements


27

Masonry Cavity Walls

Top of Wall Connections

<p>CMU Backup Long Slab Overhang Angle at Slab</p>	<p>CMU Backup Short Slab Overhang Hung Angle</p>	<p>Metal Stud Backup Long Slab Overhang Hung Angle</p>
--	--	--


28



Masonry Cavity Walls

Durability

The diagram illustrates a cross-section of a masonry cavity wall. On the left is a brick masonry unit. A steel hanger assembly is attached to the exterior face of the masonry. This assembly consists of a vertical hanger bolt that passes through the masonry and is secured with a nut and washer. The hanger bolt is connected to a horizontal metal flashing. Below the flashing is a galvanized shelf angle that is bolted to a structural steel member. The interior face of the masonry is covered with a waterproof membrane. Behind the membrane is a cavity containing insulation. Labels with arrows point to the following components: Steel Hanger Assembly, Cavity and Insulation, Waterproof Membrane, Metal Flashing, and Galvanized Shelf Angle.

29

Masonry Cavity Walls

Design of Shelf Angles

- Grimm and Yura (1989)
- Tide and Krogstad (1993)

SHELF ANGLES FOR MASONRY VENEER
By Clayford T. Grimm,¹ Fellow, ASCE, and Joseph A. Yura,²
Member, ASCE

ABSTRACT: Inadequacies of design, construction, and maintenance associated with shelf angles supporting masonry veneer on structural frames often cause spalling, cracking, and staining of masonry veneer; yielding and slipping of shelf angles.

Raymond H. R. Tide¹, Norbert V. Krogstad²

ECONOMICAL DESIGN OF SHELF ANGLES

REFERENCE: Tide, Raymond H. R., Krogstad, Norbert V., "Economic Design of Shelf Angles," *Masonry, Design and Construction, Problems and Repair*, ASTM STP 1180, John M. Melander and Lynn R. Lauersdorf, Eds., American Society for Testing and Materials, Philadelphia, 1993.

30

Masonry Cavity Walls

Shelf Angle Tables

Table 7-1. Vertical Deflection at Tip of Shelf Angle, in.
Supporting 10 Vertical Feet of Brick¹

Angle	Thickness, in.	Spacing of Angle Attachment to Structure, in.								
		24	30	36	42	48	54	60	66	72
L5x5	5/16	0.0258	0.0329	0.0399	0.0467	0.0534	0.0651	0.0788	0.0949	0.114
	3/8	0.0151	0.0193	0.0234	0.0274	0.0316	0.0386	0.0468	0.0565	0.0679
	7/16 ^(B)	0.00965	0.0123	0.0149	0.0175	0.0204	0.0250	0.0304	0.0368	0.0444
L6x4 (LLH)	1/2	0.00653	0.00834	0.0101	0.0119	0.0140	0.0171	0.0209	0.0254	0.0307
	5/8	0.00340	0.00435	0.00527	0.00618	0.00743	0.00917	0.0113	0.0138	0.0168
	3/4	0.00200	0.00256	0.00311	0.00365	0.00448	0.00557	0.00689	0.00851	0.0105
L6x4 (LLH)	5/16	0.0491	0.0624	0.0755	0.0883	0.1008	0.117	0.142	0.171	—
	3/8	0.0286	0.0364	0.0441	0.0516	0.0589	0.0694	0.0842	0.102	0.122
	7/16 ^(B)	0.0182	0.0232	0.0281	0.0328	0.0375	0.0447	0.0544	0.0659	0.0793
L6x4 (LLH)	1/2	0.0123	0.0156	0.0189	0.0222	0.0253	0.0305	0.0373	0.0452	0.0547
	9/16 ^(B)	0.00870	0.0111	0.0134	0.0157	0.0179	0.0219	0.0268	0.0327	0.0397
	5/8	0.00639	0.00813	0.00985	0.0115	0.0132	0.0163	0.0200	0.0245	0.0299
L6x4 (LLH)	3/4	0.00374	0.00477	0.00578	0.00676	0.00793	0.00985	0.0122	0.0151	0.0186


Notes:
 1. Back to all cast, aluminum alloy members (A136 or A136-SS).
 2. Angle to be used for supporting 10 feet and minimum 20 feet.
 3. Angle to be used for supporting 10 feet and minimum 20 feet.
 4. Cast aluminum alloy angle all dimensions are in inches. All dimensions are in inches unless otherwise noted.
 5. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 6. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 7. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 8. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 9. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 10. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 11. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 12. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.
 13. Dimensions are based on the thickness of the angle. The angle shall be attached to the structure with the back to the structure.



31

Masonry Cavity Walls

Hung Shelf Angle




(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)



32

Masonry Cavity Walls

Example Drawing Detail

Thermal Isolation Pad



35

Masonry Cavity Walls

Example Drawing Detail

Thermal Isolation Pad



36



Masonry Cavity Walls

Plan Locations of Hangers

Building Column
 Spandrel Beam
 Masonry Veneer

(b) Hung Shelf Angle at Re-Entrant Corner

NOTES:

- ① Shelf angle.
- ② Hangers.
- ③ Brackets from spandrel to hangers.
- ④ Allow clearance from last bracket hanger to column for column connection - 12 to 18 inches is usually sufficient.
- ⑤ Design shelf angle for cantilever past last hanger on spandrel - 18 to 24 inches is not unusual.
- ⑥ Gap between shelf angles - 1/2 inch +/- 1/2 inch. Gaps in angles and vertical control joints need not align.
- ⑦ Field install adjustable brackets from column to support ends of shelf angles if cantilever from last bracket is too long.



37

Masonry Cavity Walls



Plan Locations of Hangers

Building Column
 Spandrel Beam
 Masonry Veneer

(c) Hung Shelf Angle at Building Corner




38



Masonry Cavity Walls

Long Hangers

(See preceding slide)


NOTES:

<ul style="list-style-type: none"> ① Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown. ② Block or metal stud backup wall. ③ Spandrel beam. ④ Full depth fitted stiffener plates provide brackets that project from the spandrel beam to pick up the hanger. ⑤ Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding. ⑥ Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment. ⑦ Continuous plate to support backup wall above movement joint. Welded to hangers. 	<ul style="list-style-type: none"> ⑧ Kickers. Field weld to connection plates after adjustment of hangers. ⑨ Roll beam to restrain twist on spandrel due to eccentricity of hanger. Can also help get horizontal force from kicker into slab. ⑩ Nominal overhang of the backup allows for field adjustment of the face of backup relative to the slab edge. ⑪ Clearance is required between the inside edge of the hanger and the outside tips of the spandrel's flanges. ⑫ Horizontal soft joint in the veneer. ⑬ Backup connection to hanger assembly provides out-of-plane restraint only. Allows vertical and in-plane movement. ⑭ Interior beam resists vertical force from kicker. Consider bottom flange may go into compression and be unbraced if there is net uplift.
---	--


41

Masonry Cavity Walls

Long Hangers



Idealized Model with Pin at Hanger

Idealized Model with Pin at Spandrel Beam Web


42

Masonry Cavity Walls

Additional Rotation in Long Hangers

NOTES:

- ① If connection of the kicker to the hanger is a pin, only the hanger resists rotation of the shelf angle. Check stiffness and strength of hanger.
- ② If connection of the kicker to the hanger is rigid, the hanger and kicker resist rotation of the shelf angle. Check stiffness and strength of both.
- ③ There can be differential deflection between supports which will impact shelf angle deflection.



43

Masonry Cavity Walls

Other Concepts for Long Hangers

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)

NOTES:

- ① Fewer, heavier hangers. Perhaps at 1/4 or 1/3 span of the spandrel beam. Double angles or channels may be appropriate.
- ② HSS + shelf angle assembly spans between hangers. HSS takes torsion from eccentric shelf angle. Support HSS at columns to avoid heavy hangers adjacent to columns.
- ③ Design connection between HSS and hangers for vertical and horizontal field adjustment. Consider erection bolts in slotted holes and field welding.
- ④ Kicker.



44

Masonry Cavity Walls

Other Concepts for Long Hangers

NOTES:

- ① Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- ② Block or metal stud backup wall.
- ③ Finish may prevent the use of kickers down to shelf angle.
- ④ Full depth stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.
- ⑤ Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.
- ⑥ Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.
- ⑦ Continuous girt spans between columns for out of plane wall loads and the horizontal force that results from eccentric load on hanger. Also supports the backup wall above movement joint. Welded to hangers for vertical support.
- ⑧ Kicker to resolve eccentric forces on spandrel beam.

45

Masonry Cavity Walls

Hung Angle – Back Up Runs By Slab

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)

46

Masonry Cavity Walls

Hung Angle – Back Up Runs By Slab

(See preceding slide)

NOTES:


- ① Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- ② Metal stud backup wall runs by edge of slab.
- ③ Spandrel beam.
- ④ Full depth stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.
- ⑤ Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.
- ⑥ Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.
- ⑦ Continuous plate to support backup wall above movement joint. Welded to hangers.
- ⑧ Kickers or roll beams to restrain twist on spandrel due to eccentricity of hanger.
- ⑨ Metal studs have lateral anchor by means of a continuous clip to top of slab, or individual clips for each stud to edge of slab.
- ⑩ Nominal gap by design between backup and slab edge allows for field adjustment of the face of backup relative to the slab edge.
- ⑪ Clearance is required between the inside edge of the hanger and the outside tips of the spandrel's flanges.
- ⑫ Windows can be strip windows in this detail as the studs sit on the hanger assembly and cantilever up by the edge of slab.
- ⑬ Window head connection to hanger assembly provides out-of-plane restraint only. Allows vertical and in-plane movement.



47

Masonry Cavity Walls



Shelf Angle Supported At Slab Edge



(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)



48



Masonry Cavity Walls

Shelf Angle Supported At Slab Edge

NOTES:

(See preceding slide)

- ① Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- ② Metal stud or block backup wall.
- ③ Design the slab with adequate shear and flexure to overhang the spandrel and support the wall.
- ④ Provide a steel angle or bent plate as a pour stop and as a means to connect the shelf angle to the slab edge with headed studs or deformed bar anchors. Design ample in-out field adjustment of this bent plate. For additional adjustment detail for single, solid shim between angle and slab edge.
- ⑤ Field weld the shelf angle to the bent plate. If alternate shim detail is used, weld shim to bent plate and angle to shim.
- ⑥ Soft joint in veneer.
- ⑦ Anchorage of backup to slab. This connection needs to transfer out-of-plane forces from the wall to the slab but allow vertical movement between the slab and the lower backup wall, and in-plane movement of the wall relative to the slab for story drift of the frame.
- ⑧ Provide clearance between the backup wall and the outside tips of the spandrel beam flanges to allow the backup wall to be connected to the underside of the bent plate at the slab overhang.
- ⑨ Solid shims of varying thicknesses provide additional field in-plane/out-of-plane adjustment.



51

Masonry Cavity Walls

Potential Problems

- Inadequate provisions for the shelf angle adjustment:
 - Too little masonry bearing on shelf angle
 - Cavity too wide for specified masonry ties
- Flashing design does not accommodate projection of bolts or fasteners into the cavity at the shelf angle.



52

Masonry Cavity Walls

Potential Problems

- Inadequate sealant joint size
 - Thermal movement and brick growth
 - Spandrel beam deflections movements
- Support details at corners and atypical conditions are not clearly documented in the design.



53

Panelized Façade Systems

Panelized Façade Systems



The most important strategy for support of panelized facade systems is to support the weight of each panel on no more than two points.



54

Panelized Façade Systems

Types of Panelized Façade Systems



EFS Panels



Thin Stone Veneer



GFRP Panels



Panelized Brick on Studs




Precast Panels

55

Panelized Façade Systems

General Description




56



Panelized Façade Systems

Strategies for Support





KEY:
 ↓ ↑ Indicates direction of in-plane load resistance.
 × Indicates out-of-plane load resistance.



57

Panelized Façade Systems

Support of Backup Frame



Thin panel material

Backup Frame

Two gravity support clips

Two tie-back points



58



Panelized Façade Systems

Parameters Affecting Design


- Architectural Layout
- Relative Movements
- Magnitude of Lateral Loads
- Field Adjustability
- Durability



59

Panelized Façade Systems

Layout of Panels



- Architectural
- Shipping and erection
- Economics


Legend:
■ - Individual Panel
--- - Line of Structure
X - Window Opening



60

Panelized Façade Systems

Movement




- Vertical
 - Horizontal soft joints
- Lateral
 - Volume change
- In-plane story drift
- Out-of-plane
 - Wind, seismic
 - Bowing



61

Panelized Façade Systems

Lateral Forces



62

Panelized Façade Systems

Field Adjustability

See Alternate Connection
Shims
Leveling Bolt
Alternate



63

Panelized Façade Systems

Fire Safing

- Approved materials
- Securely installed
- Prevents passage of flame and hot gases



64



Panelized Façade Systems

Connection Types

SECTION A (SOLID WALL OR WINDOW WALL PANEL) SECTION A

● TIE-BACK CONNECTION
 ▲ BEARING CONNECTION

(Taken from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22)



65

Panelized Façade Systems

Connection Types

Bearing Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)



66

Panelized Façade Systems

Connection Types

Tie-back connections

(Adapted from reference *Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.*)

67

Panelized Façade Systems

Connection Types

Tie-back connections for limited access.

(Adapted from reference *Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.*)

68



Panelized Façade Systems

Connection Types

Alignment Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)



69

Panelized Façade Systems

Connection Types

Alignment Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)



70



Panelized Façade Systems

Column-Supported Story-Tall Panels

NOTES:

- 1 Shim stack (or leveling bolt) bearing support at panel joint. Joint to allow differential vertical movement.
- 2 Steel bracket bearing connection. Typically designed by the SSE.
- 3 Tie-back connection at top of lower panel to allow vertical and horizontal relative movement.
- 4 Stiffener plates (as required). Consider impact of stiffeners on the out-of-plane spandrel beam connection.
- 5 Maximum allowable eccentricity (e_f) specified by the Structural Engineer of Record.



71

Panelized Façade Systems

Spandrel-Supported Panels



NOTES:

- 1 Blockout in slab for bearing connection.
- 2 Bearing clip and connection to precast is typically specified by the SSE. Connection to panel is designed for moment to resolve eccentricity (e_f).
- 3 Panel joint allows relative movement between panels.
- 4 Slotted (or threaded) insert tie-back connection allows vertical and in-plane relative movement.
- 5 Steel shape hanger from spandrel to receive tie-back connection.
- 6 Steel shape kicker to resist tie-back alone and avoid torsion on spandrel.
- 7 Stiffener plates, if required, for local flange bending for bearing clip on hanger.

Detail at Composite Deck Floor Slab



72



Panelized Façade Systems

Potential Problems

- Joints in architectural elevations are not coordinated with the points of load application to the primary structure as anticipated by the SER.
- Inadequate coordination and accommodation for adjustability results in greater eccentricities than anticipated by the SER, SSE, or both.



75

Panelized Façade Systems

Potential Problems

- Attachments designed by the SSE may inadvertently:
 - Deliver moments or otherwise load the primary structure with eccentric loads not anticipated by the SER designing the primary structure.
 - Resolve horizontal and vertical kicker loads to lightweight roof elements that are not designed for the kicker loads.
 - Apply loads to the bottom flange of the spandrel.



76

Aluminum Curtain Wall Systems

Aluminum Curtain Walls




Often the most important part of the aluminum curtain wall design is anchorage adjustability to the base building structure.



77

Aluminum Curtain Wall Systems

General Description



"STICK BUILT"



78

Aluminum Curtain Wall Systems

General Description

"UNITIZED"

79

The diagram illustrates a unitized aluminum curtain wall system. It shows a grid of panels with a central window unit. Callout 1 points to the top horizontal attachment detail, and callout 2 points to the vertical attachment detail of the window unit. The AISC logo is in the bottom left corner.

Aluminum Curtain Wall Systems

General Description

"UNIT AND MULLION"

80

The diagram illustrates a unit and mullion aluminum curtain wall system. It shows a grid of panels with a central window unit. Callout 1 points to the top horizontal attachment detail, callout 2 to the vertical attachment detail of the window unit, callout 3 to the top horizontal attachment detail of the window unit, and callout 4 to the vertical attachment detail of the window unit. The AISC logo is in the bottom left corner.



Aluminum Curtain Wall Systems

Strategies for Support

- Easily accessible attachments
- Adjustability
- Limit eccentricity
- Block-outs of fire proofing
- Factory drilled bolt holes in curtain wall
- Field-welded connections




81

Aluminum Curtain Wall Systems

Strategies for Support


Dead + Lateral Attachment



NOTES:

- 1 Dead load attachment. Curtain wall hangs from roof structure in this example. Attachment detail needs to provide vertical and horizontal adjustments.
- 2 Wind load attachment. Detail provides out-of-plane support of mullion and allows vertical movement relative to structure.

Lateral Attachment



82



Aluminum Curtain Wall Systems

Architectural Parameters

- Location of mullions
- Joints
- System type
- Story height
- Acceptable mullion size
- Direction of span



83

Aluminum Curtain Wall Systems

Accommodating Thermal Movements


- Critical to performance
- Aluminum: $\alpha_{Al} \approx 13 \times 10^{-6}$ in/in/°F
- Steel: $\alpha_S \approx 6.5 \times 10^{-6}$ in/in/°F
- Concrete: $\alpha_C \approx 5.4 \times 10^{-6}$ in/in/°F
- Façade temperatures may be 4 times the interior temperature



84

Aluminum Curtain Wall Systems

Accommodating Structural Movements




- Out-of-Plane:
 - L/175 for curtain wall
 - L/360 for members also supporting brittle finishes
 - Max. of 3/4 in.
- In-Plane:
 - L/360 common but may vary



85

Aluminum Curtain Wall Systems

Field Adjustability – Gravity Anchor



Design Clearance

Curtain Wall



Structural Fasteners, Typ.

Erection Fastener

Fillet Weld



86



Aluminum Curtain Wall Systems

Attachment to Spandrel Beam

89

Aluminum Curtain Wall Systems

Attachment to Spandrel Beam

Movable anchor attached to face of spandrel beam

90



Aluminum Curtain Wall Systems

Attachment to Top of Slab

Movable anchor located on top of floor slab



91

Aluminum Curtain Wall Systems

Attachment to Top of Slab

Fixed anchor for top of mullion, movable anchor for bottom of mullion above, located in pocket cast in top of floor slab



92



Aluminum Curtain Wall Systems

Attachment to Top of Slab

Fixed anchor for top of mullion, movable anchor for bottom of mullion above, located on top of floor slab



93

Aluminum Curtain Wall Systems

Potential Problems

- Large gaps between the anchors and the primary building structure can result in excessive bending stresses.
- Coordination of locations for adjustment.
- Slotted holes must be long enough to accommodate adjustment.



94

Aluminum Curtain Wall Systems

Potential Problems

- Coordination of bolted attachments to the primary building structure.
- Mullion splices should properly account for volume changes and movement of the primary building structure.



95

Sizing Joints for Vertical Movement

Sizing Joints for Vertical Movement



Facade joints are building components just like mechanical or structural components and need to be explicitly **designed**.




96

Sizing Joints for Vertical Movement

Joint Fundamentals

- Joints are necessary in facades.
- Joints accommodate movement and tolerances.
- Joints control air and water - especially in barrier systems.




97

Sizing Joints for Vertical Movement


Movement Types






- Dead (Self) Load
- Superimposed Dead Load
- Live Load
- Snow/Rain Load

- Wind Load Drifts
- Seismic (Earthquake) Drifts



- Long-Term Shrinkage
- Differential Settlement
- Thermal Movements
- Moisture Movements





98

Sizing Joints for Vertical Movement

Joint Movements

- Dead Load (Self-Weight) Deflections
- Superimposed Dead Load Deflections
- Facade Weight Deflections

Pre-Service Superstructure Movements → **DO NOT*** need to be considered in the facade joint design.

Superstructure Movements during Facade Installation → **MIGHT** need to be considered in the facade joint design, depending on the facade type and its ability to be adjusted after installation.

99

Sizing Joints for Vertical Movement

Joint Movements

- Live Load Deflections
- Snow/Rain Load Deflections
- Wind Load Deflections/Drift
- Seismic Deflections/Drift
- Long-Term Shrinkage
- Differential Settlement

In-Service Superstructure Movements → **MUST** be considered in the facade joint design.

- Thermal Movements
- Moisture Movements

In-Service Facade Movements → **MUST** be considered in the facade joint design.

100

Sizing Joints for Vertical Movement

Vertical Joint Movements Façade Loads

- Weight of façade causes spandrel beam to deflect vertically
- Spandrel beam may twist under weight of façade at slab edge
- Twisting motion translates to additional façade joint closure



101

Sizing Joints for Vertical Movement


Vertical Joint Movements Live, Snow, and Rain Loads




102

Sizing Joints for Vertical Movement

Vertical Joint Movements Live, Snow, and Rain Loads





Potential “pinch points” include:

- Floors with different design live loads
- Unloaded floor beneath loaded floor
- Floor level immediately below the roof
- First level above foundation wall/base of facade

103

Sizing Joints for Vertical Movement

Vertical Joint Movement Creep and Column Shortening

- Creep deformations over time in concrete buildings
- Column shortening in tall buildings, particularly at lower floors




104

Sizing Joints for Vertical Movement

Vertical Joint Movement Differential Settlement

- Anticipated building foundation differential settlement (if any) must be accounted for in design of facade joints



105

Sizing Joints for Vertical Movement

Façade Movements Thermal Changes

- Building superstructure typically is fully enclosed within building thermal envelope
- Façade elements must be designed to accommodate thermal movements:
 - Morning to Night
 - Winter to Summer



106

Sizing Joints for Vertical Movement

Facade Movements Thermal Changes

- Coefficient of Linear Thermal Expansion of Common Building Materials

$$M = \Delta T * L * \alpha$$

↑ Thermal movement
↑ Max Temperature Range
↑ Length
↑ Coefficient of Linear Thermal Expansion

Construction Material	in/in/°F × 10 ³
CLAY MASONRY	
Brick, Clay or Glaze	3.6
Brick, Fire Clay	3.1
Tile, Clay or Glaze	3.3
Tile, Fire Clay	2.8
CONCRETE	
Gravel Aggregate	6.0
Lightweight Structural	4.5
CONCRETE MASONRY	
Crusher Aggregate	5.1
Crusher Aggregate	5.2
Expanded-Shale Aggregate	4.3
Expanded-Slag Aggregate	4.6
Various Porch and Aggregate	4.1
EXTERIOR INSULATION FINISH SYSTEMS	
EIFS - Light Colored	7.8
EIFS - Dark Colored	10.0
METALS	
Aluminum (3003 Alloy)	13.2
Steel, A36	6.5
Steel, A572	6.6
Copper, 110	16.8
Cast Iron	6.8
Cast Steel	6.5
Wrought Iron	6.5
Lead, Common	7.4
Manila	16.3
Stainless Steel	7.8
Aluminum Type 302	16.0
Aluminum Type 304	16.0
Structural Steel	6.5
Zinc	15.3
GLASS	
Plate	5.1
PLASTER	
Organic Aggregate	7.6
Particle	6.2
Vermiculite Aggregate	6.4
PLASTICS	
Acrylic	40-50
Aluminum	37-50
Asphalt	20-25
Phenolic	28
PVC	10-14
Vinyl	23
Other	34-40
STONE	
Granite	6.0
Limestone	5.5
Marble	7.3

107

Sizing Joints for Vertical Movement

Facade Movements Thermal Changes

- Thermally-broken curtainwall system will exhibit some differential thermal stresses.
- Slight bowing of the frame (dependent upon the thermal break's ability to transfer shear forces)
- For facade joint sizing, conservatively assume NO thermal break within curtainwall system.

Alum. frame bowing due to thermal expansion

Alum. frame bowing due to thermal contraction

downwards deflection


no deflection

108

Sizing Joints for Vertical Movement

Façade Movements Moisture Changes

- Most relevant for masonry and stone
- Brick masonry expands irreversibly due to water absorption by 0.02 – 0.07%.



The diagram on the left shows a brick wall with blue arrows indicating expansion: one pointing up, one pointing left, and one pointing right. A label 'Direction of Expansion' points to the upward arrow. To the right is a photograph of a brick building with several windows.




109

Sizing Joints for Vertical Movement

Joint Types: Sealant

- Medium Modulus Silicone Sealant
 - +50% / -50% typical movement capacity
 - Not all sealant has the same movement capacity
 - Need to confirm with manufacturer's product data



The diagram shows a 3D perspective of a sealant joint. Yellow arrows indicate 'LONGITUDINAL SHEAR' along the top and bottom surfaces. Green arrows indicate 'TRANSVERSE SHEAR' along the vertical faces. Red arrows pointing away from each other indicate 'TENSION', and blue arrows pointing towards each other indicate 'COMPRESSION'. Dimensions 'W' and 'SI' are also shown.




110

Sizing Joints for Vertical Movement

Joint Types: Extruded Silicone Sheet


- Typical Capacities
- +200% capacity
- -75% capacity


111

Sizing Joints for Vertical Movement

Joint Types: Extruded Silicone Sheet


112



Sizing Joints for Vertical Movement

Load Combinations for Joint Design

- The building code provides some guidance on load combinations, but no specific requirements.
- Serviceability checks may allow lower forces and drifts; for example joint sealant movements.
- ASCE 7-16 Commentary suggests:

$$D + 0.5L + W_a$$



113

Sizing Joints for Vertical Movement

Sizing Horizontal Façade Joints

$$J' = \frac{\alpha \Delta_T h + k_e h + \delta_{sil}}{M} + Tol + \delta_{ps}$$

- α = coeff. thermal exp.
- k_e = coeff. Moisture exp.
- Δ_T = design temp. change
- h = vertical spacing between joints
- δ_{sil} = deflection after sealant is installed
- M = compressibility of sealant material
- Tol = allowance for tolerance
- δ_{ps} = deflection prior to sealant installation



114



Sizing Joints for Vertical Movement

Example 7.1: Determination of Deflections for Structures Supporting Brick Veneers


For the clay brick veneer on a building supported at each floor level by a shelf angle, determine the amount by which the brick will expand and the amount by which the spandrel beam can deflect before compressing the joint filler material to its maximum allowable compressibility.



115

Sizing Joints for Vertical Movement

Example 7.1



116



Sizing Joints for Vertical Movement

Example 7.1

Given:

The brick height between the shelf angles, $h = 14$ ft. The vertical as-built construction tolerance of the building, $Tol = 1/8$ in. The shelf angle deflection under the weight of the brick with respect to the floor below, $\delta_a = 1/16$ in.

The brick veneer is installed at an ambient temperature of 40 °F. The exterior wall of the building may experience a change in temperature, $\Delta_T = 100$ °F. The brick coefficient of thermal expansion, $\alpha = 4 \times 10^{-6}$ in./in./°F, and the brick coefficient of moisture expansion, $k_e = 3 \times 10^{-4}$ in./in.

The largest design gap width before sealant installation, $J' = 7/8$ in. The joint filler material is a high-performance sealant and the compressibility of the sealant material, $M = 50\%$.




117

Sizing Joints for Vertical Movement

Example 7.1

Step 1: Determine the amount by which the brick will expand.

Width of sealant joint	$J = 0.875$ in.
Compressibility of sealant material	$M = 50\%$
Anticipated construction vertical tolerance	$Tol = 0.125$ in.
Shelf angle deflection	$\delta_a = 0.0625$ in.
Brick coefficient of thermal expansion	$\alpha = 4(10^{-6})$ in./in.°F
Brick coefficient of moisture expansion	$k_e = 3(10^{-4})$ in./in.
Height of brick between shelf angles	$h = 14$ ft
Change in temperature	$\Delta_T = 100^\circ F$





118

Sizing Joints for Vertical Movement

Example 7.1

The design gap before sealant is installed with may be expressed by the following equation:



$$J' = J + Tol + \delta_{ps}$$

$$J' = \frac{\alpha \cdot \Delta_T \cdot h + k_e \cdot h + \delta_{sil}}{M} + Tol + \delta_{ps}$$

$$\delta_{sil} + M\delta_{ps} = M(J' - Tol) - (\alpha\Delta_T h + k_e h)$$

$$\delta_s = \delta_{sil} + M\delta_{ps}$$

$$\delta_{vb} = k_e h + \alpha\Delta_T h$$


Note that the shelf angle deflection includes deflection of the horizontal leg of the angle as well as the deflection of the shelf angle between attachments to the building structure.



Sizing Joints for Vertical Movement

Example 7.1

The volume change of the brick between the shelf angles is,



$$\delta_{vb} = k_e h + \alpha\Delta_T h$$

$$= (3 \times 10^{-4} \text{ in./in.})(14 \text{ ft})(12 \text{ in./ft})$$

$$+ (4 \times 10^{-6} \text{ in./in./}^\circ\text{F})(100 \text{ }^\circ\text{F})(14 \text{ ft})(12 \text{ in./ft})$$


$$= 0.118 \text{ in.}$$



Sizing Joints for Vertical Movement

Example 7.1

The amount of movement that the joint can accommodate is,

$$\begin{aligned} \delta_{jm} &= M(J' - Tol) \\ &= 0.50 \left(\frac{7}{8} \text{ in.} - \frac{1}{8} \text{ in.} \right) \\ &= 0.375 \text{ in.} \end{aligned}$$


Thus, the permissible structural deflection, including the deflection due to the loads applied prior to installation of the sealant joint is,

$$\begin{aligned} \delta_s &= \delta_{jm} - \delta_{vb} \\ &= 0.375 \text{ in.} - 0.118 \text{ in.} \\ &= 0.257 \text{ in.} \end{aligned}$$


121

Sizing Joints for Vertical Movement

Example 7.1


The total structural deflection is $\delta_{sil} + M\delta_{ps}$, where

$$\delta_{ps} = \delta'_{sb} + \delta_a$$

The deflection of the spandrel beam, δ'_{sb} , due to the brick load and δ_a is the total deflection of the shelf angle due to the brick load. Substituting this quantity back into the equation for the total structural deflection, and limiting the total to not exceed δ_s ,

$$\delta_{sil} + M\delta'_{sb} + M\delta_a \leq \delta_s$$

The deflection of the spandrel beam is proportional to the load on it. Knowing that the uniformly distributed load due to the brick on the spandrel is w_{sb} and the superimposed load is w_{sil} , the deflection of the spandrel beam due to the uniformly distributed load due to the brick is,


$$\delta'_{sb} = \delta_{sil} \frac{w_{sb}}{w_{sil}}$$



122

Sizing Joints for Vertical Movement

Example 7.1

This ratio assumes that the interior beams are parallel to the spandrel beam and do not frame into the spandrel beam. The assumption may still be a reasonable approximation when floor beams frame to the spandrel beam. Substituting this relationship back into the equation for δ_s above gives,



$$\delta_{sil} + M \left(\delta_{sil} \frac{w_{db}}{w_{sil}} \right) + M\delta_a \leq \delta_s$$

Rearranging this for δ_{sil} , the amount the spandrel beam can deflect is,


$$\begin{aligned} \delta_{sil} &\leq \frac{\delta_s - M\delta_a}{1 + M \left(\frac{w_{db}}{w_{sil}} \right)} \\ &\leq \frac{0.257 \text{ in.} - 0.50 \left(\frac{1}{16} \text{ in.} \right)}{1 + 0.50(1)} \\ &\leq 0.151 \text{ in.} \end{aligned}$$



Sizing Joints for Vertical Movement

Example 7.1

This calculation requires the designer to make assumptions about the brick and superimposed loads on the beam, which may be difficult during preliminary design. In practice, it is conservative and often easier to use the total of the brick deflection and the superimposed load deflection such that:



$$\delta_s = \delta_{ps} + \delta_{sil}$$

Note that at the first elevated floor level where the brick below the shelf angle is supported on a foundation wall, δ_{ps} may be significant. At upper floor levels, however, where the spandrel beam on the floor below the shelf angle may deflect approximately as much as the spandrel beam supporting the shelf angle in question, δ_{ps} may be small. Thus, one can often conservatively select a beam for which the total deflection associated with cladding loads, superimposed dead loads, and live loads is less than δ_s .



Sizing Joints for Vertical Movement

Effects of Vertical Movements on Vertical Joints

Vertical Movements

Effect on **horizontal** joint due to **vertical** movement.

Effect on **vertical** joint due to **vertical** movement.

Undeformed

Deformed

Undeformed



125

Sizing Joints for Vertical Movement

Effects of Horizontal Movements on Vertical Joints

Horizontal Movements

Effect on **horizontal** joint due to horizontal movement.

Effect on **vertical** joint due to **horizontal** movement.

wind

interlock corner panel



126



AISC | Questions?



**Smarter.
Stronger.
Steel.**

Single-Session Registrants

CEU / PDH Certificates

- You will receive an email on how to report attendance from: registration@aisc.org.
- Be on the lookout: Check your spam filter! Check your junk folder!
- Completely fill out online form. Don't forget to check the boxes next to each attendee's name!



**Smarter.
Stronger.
Steel.**



Single-Session Registrants

CEU / PDH Certificates

- Reporting site (URL will be provided in the forthcoming email).
- Username: Same as AISC website username.
- Password: Same as AISC website password.



4-Session Registrants

CEU / PDH Certificates

One certificate will be issued at the conclusion of the course.



4-Session Registrants

Attendance and PDH Certificates

- For Session R1, you must pass the quiz to receive credit for the session.
- For Sessions L1 – L3, you have two options to receive credit for the session.
 - Option 1: Watch the live session. Credit for live attendance will be displayed on the Course Resources table within two days of the session.
 - Option 2: Watch the recording and pass the associated quiz.

Videos and Quizzes

- Session R1 video recording and quiz access has been available since you registered.
- For Sessions L1 – L3, find access by the end of the day, Friday, after the live air date. (An email will be sent from webinars@aisc.org.)
- All video recordings and quizzes are available until 8:00 a.m. ET on June 17.
- Quiz scores are displayed in the Course Resources table.

Distribution of Certificates

All certificates will be issued after the course is completed (the week of June 17). Only the registrant will receive a certificate for the course.



4-Session Registrants

Course Resources


Find all your handouts, quizzes and quiz scores, recording access, and attendance information in one place!



4-Session Registrants

Course Resources


Go to www.aisc.org and sign in.



4-Session Registrants

Course Resources

Go to www.aisc.org and sign in.



4-Session Registrants

Course Resources

Event	Start Date
Systems Design in Steel	1/1/2000 12:00:00 AM
4-Session Package-Design of Façade Attachments	5/9/2019 1:00:00 PM
102_15 B-Session Package-Night School 15 - Fundamentals of Connection Design	10/3/2017 7:00:00 PM
102_16 B-Session Package-Night School 16 - Systems Design in Steel	2/3/2018 7:00:00 PM
102_17 B-Session Package-Night School 17 - Design of Façade Attachments	7/18/2018 7:00:00 PM
102_18 B-Session Package-Night School 18 - Steel Construction: All The Topics Out	10/15/2018 7:00:00 PM
102_19 B-Session Package-Night School 19 - Connection Design	2/14/2019 7:00:00 PM
102_20 B-Session Package-Night School 20 - Classical Methods of Structural Analysis	8/3/2019 7:00:00 PM
8-Session Package-Systems Design in Steel - Concrete & Brackets	7/16/2018 1:00:00 PM

4-Session Registrants

Course Resources

4-SESSION PACKAGE RESOURCES

Event	Date	Handouts	Videos	Quiz	Attendance
R1: Façade Fundamentals	N/A	Handouts	Video Passcode: AZN6175	Pass Score: 100	N/A
L1: Façade Attachments Part 1	May 9 2019 1:30PM EDT	Handouts	Available 05/11/2019 5:00PM EDT	Available 05/11/2019 5:00 PM EDT	Pending
L2: Façade Attachments Part 2	May 18 2019 1:30PM EDT	Handouts	Available 05/18/2019 5:00PM EDT	Available 05/18/2019 5:00 PM EDT	Pending
L3: Façade Attachments - Building Lateral Drifts	May 23 2019 1:30PM EDT	Handouts	Available 05/25/2019 5:00PM EDT	Available 05/25/2019 5:00 PM EDT	Pending
Final Exam	N/A			Available 5/27/2019 5:00 PM EDT	



