

AISC Live Webinars

Thank you for joining our live webinar today.
We will begin shortly. Please standby.

Thank you.

Need Help?
Call ReadyTalk Support: 800.843.9166

Design of Façade Attachments

Session L1: Façade Attachments, Part 1
May 9, 2019



AISC Live Webinars

Today's live webinar will begin shortly. Please stand by.

As a reminder, all lines have been muted. Please type any questions or comments through the chat feature on the left portion of your screen.

Today's audio will be broadcast through the internet.
Alternatively, to hear the audio through the phone, dial:

(800)-581-5838
Passcode: 959842



AISC Live Webinars

Audio Options

Today's audio will be broadcast through the internet.

Alternatively, to hear the audio through the phone, dial:

(800)-581-5838
Passcode: 959842



AISC Live Webinars

AIA Credit

AISC is a Registered Provider with The American Institute of Architects Continuing Education Systems (AIA/CES). Credit(s) earned on completion of this program will be reported to AIA/CES for AIA members. Certificates of Completion for both AIA members and non-AIA members are available upon request.

This program is registered with AIA/CES for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product.

Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.



AISC Live Webinars

Copyright Materials

This presentation is protected by US and International Copyright laws. Reproduction, distribution, display and use of the presentation without written permission of AISC is prohibited.

© The American Institute of Steel Construction 2019

The information presented herein is based on recognized engineering principles and is for general information only. While it is believed to be accurate, this information should not be applied to any specific application without competent professional examination and verification by a licensed professional engineer. Anyone making use of this information assumes all liability arising from such use.



AISC Live Webinars

Course Description

Façade Attachments, Part 1
May 9, 2019

Every type of facade system presents its own challenges for the design team. Where and how are the gravity and lateral loads supported? How much movement can the facade system accommodate? What is the jointing pattern? In this session, we will explore masonry cavity wall systems, aluminum-glass curtain wall systems and panelized systems such as precast concrete panels or prefabricated metal-framed panels with masonry or glass-fiber reinforced concrete facing to help answer these questions.



AISC Live Webinars

Learning Objectives

- List the issues to consider when locating joints in masonry cavity walls.
- Describe how panelized façade systems are best supported.
- Explain the importance of allowing for field adjustments of aluminum curtain walls.
- Name the sources of vertical movement in façade systems.



Design of Façade Attachments

Session L1: Façade Attachments, Part 1
May 9, 2019



Alec Zimmer, PE
Senior Project Manager
Simpson Gumpertz & Heger Inc.
Waltham, MA



Syllabus for Webinar Series Sessions

- **Session R1**
 - Fundamentals of Facades
 - Design Criteria
- Session L1
 - Design and Execution Responsibilities
- Session L2
 - Thermal Bridging
- Session L3
 - Planning for Clearances
 - Accommodating Tolerances



9

Syllabus for Webinar Series Sessions

- Session R1
- **Session L1**
 - Traditional Masonry Cavity Walls
 - Panelized Façade Systems
- Session L2
 - Aluminum-Glass Curtain Walls
- Session L3
 - Sizing Joints for Vertical Movement



10

Masonry Cavity Walls

Masonry Cavity Walls




The strategy for supporting masonry cavity walls starts with the decision for the location of the horizontal movement joints.



11

Masonry Cavity Walls

General Description






NOTES:

- 1 Veneer.
- 2 Veneer anchor.
- 3 Exterior sheathing, usually gypsum based.
- 4 Water barrier.
- 5 Insulation.
- 6 Through wall flashing.
- 7 Shelf angle.
- 8 Backup wall (metal stud shown).
- 9 Top of backup wall connection allows vertical movement between portion of wall above soft joint and portion below, plus allow in-plane movement.
- 10 Soft joint under shelf angle.



12



Masonry Cavity Walls

Strip Windows

Elevation

Strip Window

Metal Stud Backup

Cavity Wall (Membrane, Insulation, and Flashing Not Shown for Clarity)

NOTES:

- ① Strip window. The shelf angle is at the window head.
- ② Movement joint between shelf angle assembly and window head. The window head connection provides out-of-plane support of the window.
- ③ Metal stud backup wall is supported off of the hung shelf angle assembly. Studs are connected to the edge of the slab and cantilever up to provide vertical and out-of-plane support at the sill of the strip window.
- ④ At the roof, the metal studs cantilever up past the slab edge to form the parapet.
- ⑤ Kickers or roll beams can resist the twist of the spandrel beam.
- ⑥ The finish ceiling location may dictate the location of the kickers.
- ⑦ Lateral tie to slab so studs can cantilever by edge of slab up to sill of window for out-of-plane support of window.




17

Masonry Cavity Walls

Parameters Affecting Design

- Architecture Decisions
 - Fenestration
 - Horizontal Joint Patterns
 - Vertical Joint Patterns
- Dimensions
 - Story Heights
- Magnitude of Loads
- Field Adjustability
- Relative Movements
- Durability
- Thermal Performance




18

Masonry Cavity Walls

Architectural Decisions

Ceilings, MEP



19

Masonry Cavity Walls

Architectural Decisions

Vertical Control Joints



20

Masonry Cavity Walls

Dimensions

NOTES:

- 1 Shelf angle made from standard rolled angle shape.
- 2 Structural spacer may be required for projects with thick insulation requirements in the cavity or with thick veneer in order to keep standard rolled angle as shelf.
- 3 Line of membrane and flashing.
- 4 A minimum of 2/3 of the veneer should bear on the shelf angle.
- 5 Continuous plate to support backup wall above.
- 6 Structural hangers behind membrane and within the thickness of the backup wall.

21

Masonry Cavity Walls

Dimensions

22

Masonry Cavity Walls

Field Adjustability

- Slab edge
- Backup wall
- Shelf angle

23

Masonry Cavity Walls

Vertical Movements

$ke h + \alpha \Delta h$
 $h = \text{story ht.}$

Design Vertical Movements

Note: Column shortening is important too for tall building's bottom story.

24

Masonry Cavity Walls

Joint Compressibility

$\pm 30\% J$

J



25

Masonry Cavity Walls

In-Plane Movements

Seismic or Wind Drift



26

Masonry Cavity Walls

In-Plane Movements



27

Masonry Cavity Walls

Top of Wall Connections



CMU Backup Long Slab Overhang Angle at Slab	CMU Backup Short Slab Overhang Hung Angle	Metal Stud Backup Long Slab Overhang Hung Angle
---	---	---



28

Masonry Cavity Walls

Durability

29

Masonry Cavity Walls

Design of Shelf Angles

- Grimm and Yura (1989)
- Tide and Krogstad (1993)

SHELF ANGLES FOR MASONRY VENEER
 By Claydon T. Grimm,¹ Fellow, ASCE, and Joseph A. Yura,² Member, ASCE

ABSTRACT: Inadequacies of design, construction, and maintenance associated with shelf angles supporting masonry veneer on structural frames often cause spalling, cracking, and staining of masonry veneer; yielding and slipping of shelf angles;

Raymond H. R. Tide¹, Norbert V. Krogstad²

ECONOMICAL DESIGN OF SHELF ANGLES

REFERENCE: Tide, Raymond H. R., Krogstad, Norbert V., "Economic Design of Shelf Angles," *Masonry: Design and Construction, Problems and Practice, ASTM STP 1180*, John H. Melander and Lynn H. Lauerdorf, Eds., American Society for Testing and Materials, Philadelphia, 1993.

30

Masonry Cavity Walls

Shelf Angle Tables

Angle	Thickness, in.	Spacing of Angle Attachment to Structure, in.									
		24	30	36	42	48	54	60	66	72	
L5x5	5/16	0.0258	0.0329	0.0399	0.0467	0.0534	0.0651	0.0788	0.0949	0.114	
	3/8	0.0151	0.0193	0.0234	0.0274	0.0316	0.0386	0.0468	0.0565	0.0679	
	7/16 ^(B)	0.00965	0.0123	0.0149	0.0175	0.0204	0.0250	0.0304	0.0368	0.0444	
L5x4	1/2	0.00653	0.00834	0.0101	0.0119	0.0140	0.0171	0.0209	0.0254	0.0307	
	5/8	0.00340	0.00435	0.00527	0.00618	0.00743	0.00917	0.0113	0.0138	0.0168	
	3/4	0.00200	0.00256	0.00311	0.00365	0.00448	0.00557	0.00689	0.00851	0.0105	
L6x4 (LLH)	5/16	0.0491	0.0624	0.0755	0.0883	0.1008	0.117	0.142	0.171	—	
	3/8	0.0286	0.0364	0.0441	0.0516	0.0589	0.0694	0.0842	0.102	0.122	
	7/16 ^(B)	0.0182	0.0232	0.0281	0.0328	0.0375	0.0447	0.0544	0.0659	0.0793	
L6x4 (LLH)	1/2	0.0123	0.0156	0.0189	0.0222	0.0253	0.0305	0.0373	0.0452	0.0547	
	9/16 ^(B)	0.00870	0.0111	0.0134	0.0157	0.0179	0.0219	0.0268	0.0327	0.0397	
	5/8	0.00639	0.00813	0.00985	0.0115	0.0132	0.0163	0.0200	0.0245	0.0299	
L6x4 (LLH)	3/4	0.00374	0.00477	0.00578	0.00676	0.00793	0.00985	0.0122	0.0151	0.0186	

31

Masonry Cavity Walls

Hung Shelf Angle

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)

32

Masonry Cavity Walls

Hung Shelf Angle

(See preceding slide)


NOTES:

<p>① Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.</p> <p>② Block or metal stud backup wall.</p> <p>③ Spandrel beam.</p> <p>④ Full depth stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.</p> <p>⑤ Single angle hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.</p> <p>⑥ Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.</p>	<p>⑦ Continuous plate to support backup wall above movement joint. Welded to hangers.</p> <p>⑧ Kickers or roll beams restrain twist of spandrel.</p> <p>⑨ Field application of light gage metal pour stop provides adjustment of slab edge location.</p> <p>⑩ Nominal overhang of the backup allows for field adjustment of the face of backup relative to the slab edge.</p> <p>⑪ Clearance is required between the inside edge of the hanger and the outside tips of the spandrel's flanges.</p> <p>⑫ Horizontal soft joint in the veneer.</p> <p>⑬ Backup connection to hanger assembly provides out-of-plane restraint only. Allows vertical and in-plane movement.</p>
--	---


33

Masonry Cavity Walls


Example Drawing Detail




34

Masonry Cavity Walls

Example Drawing Detail




Thermal Isolation Pad


35

Masonry Cavity Walls

Example Drawing Detail



Thermal Isolation Pad


36

Masonry Cavity Walls

Long Hangers

(See preceding slide)

NOTES:


- 1 Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- 2 Block or metal stud backup wall.
- 3 Spandrel beam.
- 4 Full depth fitted stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.
- 5 Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.
- 6 Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.
- 7 Continuous plate to support backup wall above movement joint. Welded to hangers.
- 8 Kickers. Field weld to connection plates after adjustment of hangers.
- 9 Roll beam to restrain twist on spandrel due to eccentricity of hanger. Can also help get horizontal force from kicker into slab.
- 10 Nominal overhang of the backup allows for field adjustment of the face of backup relative to the slab edge.
- 11 Clearance is required between the inside edge of the hanger and the outside tips of the spandrel's flanges.
- 12 Horizontal soft joint in the veneer.
- 13 Backup connection to hanger assembly provides out-of-plane restraint only. Allows vertical and in-plane movement.
- 14 Interior beam resists vertical force from kicker. Consider bottom flange may go into compression and be unbraced if there is net uplift.



41

Masonry Cavity Walls

Long Hangers




Idealized Model with Pin at Hanger Idealized Model with Pin at Spandrel Beam Web



42

Masonry Cavity Walls

Additional Rotation in Long Hangers



NOTES:


- 1 If connection of the kicker to the hanger is a pin, only the hanger resists rotation of the shelf angle. Check stiffness and strength of hanger.
- 2 If connection of the kicker to the hanger is rigid, the hanger and kicker resist rotation of the shelf angle. Check stiffness and strength of both.
- 3 There can be differential deflection between supports which will impact shelf angle deflection.



43

Masonry Cavity Walls

Other Concepts for Long Hangers



NOTES:

- 1 Fewer, heavier hangers. Perhaps at 1/4 or 1/3 span of the spandrel beam. Double angles or channels may be appropriate.
- 2 HSS + shelf angle assembly spans between hangers. HSS takes torsion from eccentric shelf angle. Support HSS at columns to avoid heavy hangers adjacent to columns.
- 3 Design connection between HSS and hangers for vertical and horizontal field adjustment. Consider erection bolts in slotted holes and field welding.
- 4 Kicker.

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)



44



Masonry Cavity Walls

Other Concepts for Long Hangers

NOTES:

- 1 Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- 2 Block or metal stud backup wall.
- 3 Finish may prevent the use of kickers down to shelf angle.
- 4 Full depth stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.
- 5 Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.
- 6 Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.
- 7 Continuous girt spans between columns for out of plane wall loads and the horizontal force that results from eccentric load on hanger. Also supports the backup wall above movement joint. Welded to hangers for vertical support.
- 8 Kicker to resolve eccentric forces on spandrel beam.

45

Masonry Cavity Walls

Hung Angle – Back Up Runs By Slab

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)

46

Masonry Cavity Walls

Hung Angle – Back Up Runs By Slab

(See preceding slide)

NOTES:

- 1 Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- 2 Metal stud backup wall runs by edge of slab.
- 3 Spandrel beam.
- 4 Full depth stiffener plates provide brackets that project from the spandrel beam to pick up the hanger.
- 5 Hangers. Erection bolts in long horizontal slots in the angle and long vertical slots in the bracket plates allow for field adjustment prior to field welding.
- 6 Shelf angle. May be shop welded if hangers have sufficient adjustment. Can have erection bolts in slotted holes with field welding after final placement for additional adjustment.
- 7 Continuous plate to support backup wall above movement joint. Welded to hangers.
- 8 Kickers or roll beams to restrain twist on spandrel due to eccentricity of hanger.
- 9 Metal studs have lateral anchor by means of a continuous clip to top of slab, or individual clips for each stud to edge of slab.
- 10 Nominal gap by design between backup and slab edge allows for field adjustment of the face of backup relative to the slab edge.
- 11 Clearance is required between the inside edge of the hanger and the outside tips of the spandrel's flanges.
- 12 Windows can be strip windows in this detail as the studs sit on the hanger assembly and cantilever up by the edge of slab.
- 13 Window head connection to hanger assembly provides out-of-plane restraint only. Allows vertical and in-plane movement.

47

Masonry Cavity Walls

Shelf Angle Supported At Slab Edge

(Note: Sheathing and Insulation Not Shown for Clarity, Typ.)

48

Masonry Cavity Walls

Example Drawing Detail

Thermal Isolation Pad

NOTES:

1. ALL STEEL BEYOND THE BENT PLATE MUST BE HOT DIP GALV.
2. CONNECTION GROUP SHALL BE SPACED AT 4'-0\"/>
- 3. BRICKWORK WITH A SHIM OR BENT PLATE MUST BE REINFORCED WITH A SHIM OR BENT PLATE AFTER EACH COURSE. BRICK CALIBRATED. POINTING BRICKS NOT POINTED.
- 4. IF OTHER BRICK MUST BE POINTED TO 30 MPsi PER TABLE 4.1.3 OF THE AISC 308 SPECIFICATION.
- 5. MUST SPECIALLY INSPECT FOR CRACKS ON ALL STEEL AND THIS OF TENSION CONTROLLED STEEL.

1 TYPICAL BRICK RELIEVING ANGLE

49

Masonry Cavity Walls

Example Drawing Detail

Thermal Isolation Pad

L4x3 1/2x3/8 LLV CONT. GALV. ANGLE, SPLICES SHALL BE BUTT WELDED IN FIELD

PL 5/16x3x9 3/4 WITH HORIZ. SSL HOLES

50

Masonry Cavity Walls

Shelf Angle Supported At Slab Edge

(See preceding slide)

NOTES:

- 1 Veneer of cavity wall. Membrane, insulation, flashing, etc. not shown.
- 2 Metal stud or block backup wall.
- 3 Design the slab with adequate shear and flexure to overhang the spandrel and support the wall.
- 4 Provide a steel angle or bent plate as a pour stop and as a means to connect the shelf angle to the slab edge with headed studs or deformed bar anchors. Design ample in-out field adjustment of this bent plate. For additional adjustment detail for single, solid shim between angle and slab edge.
- 5 Field weld the shelf angle to the bent plate. If alternate shim detail is used, weld shim to bent plate and angle to shim.
- 6 Soft joint in veneer.
- 7 Anchorage of backup to slab. This connection needs to transfer out-of-plane forces from the wall to the slab but allow vertical movement between the slab and the lower backup wall, and in-plane movement of the wall relative to the slab for story drift of the frame.
- 8 Provide clearance between the backup wall and the outside tips of the spandrel beam flanges to allow the backup wall to be connected to the underside of the bent plate at the slab overhang.
- 9 Solid shims of varying thicknesses provide additional field in-plane/out-of-plane adjustment.

51

Masonry Cavity Walls

Potential Problems

- Inadequate provisions for the shelf angle adjustment:
 - Too little masonry bearing on shelf angle
 - Cavity too wide for specified masonry ties
- Flashing design does not accommodate projection of bolts or fasteners into the cavity at the shelf angle.

52

Masonry Cavity Walls

Potential Problems

- Inadequate sealant joint size
 - Thermal movement and brick growth
 - Spandrel beam deflections movements
- Support details at corners and atypical conditions are not clearly documented in the design.



53

Panelized Facade Systems

Panelized Facade Systems




The most important strategy for support of panelized facade systems is to support the weight of each panel on no more than two points.



54

Panelized Facade Systems

Types of Panelized Facade Systems



EIFS Panels *Thin Stone Veneer*


GFRP Panels *Panelized Brick on Studs* *Precast Panels*



55

Panelized Facade Systems

General Description



56

Panelized Façade Systems

Strategies for Support

KEY:
 ↑ ↓ Indicates direction of in-plane load resistance.
 × Indicates out-of-plane load resistance.



57

Panelized Façade Systems

Support of Backup Frame

Thin panel material
 Backup Frame
 Two gravity support clips
 Two tie-back points



58

Panelized Façade Systems

Parameters Affecting Design

- Architectural Layout
- Relative Movements
- Magnitude of Lateral Loads
- Field Adjustability
- Durability



59

Panelized Façade Systems

Layout of Panels

- Architectural
- Shipping and erection
- Economics


— Individual Panel
 - - - Line of Structure
 × Window Opening



60

Panelized Façade Systems

Movement




- Vertical
 - Horizontal soft joints
- Lateral
 - Volume change
- In-plane story drift
- Out-of-plane
 - Wind, seismic
 - Bowing



61

Panelized Façade Systems


Lateral Forces



62

Panelized Façade Systems

Field Adjustability



See Alternate Connection

Shims

Leveling Bolt

Alternate




63

Panelized Façade Systems

Fire Safing

- Approved materials
- Securely installed
- Prevents passage of flame and hot gases



64

Panelized Façade Systems

Connection Types

SECTION A (SOLID WALL OR WINDOW WALL PANEL) SECTION A

● TIE-BACK CONNECTION
 ▲ BEARING CONNECTION

(Taken from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22)

65

Panelized Façade Systems

Connection Types

Bearing Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)

66

Panelized Façade Systems

Connection Types

Tie-back connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)

67

Panelized Façade Systems

Connection Types

Tie-back connections for limited access.

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)

68

Panelized Façade Systems

Connection Types

Alignment Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)

69

Panelized Façade Systems

Connection Types

Section View Elevation View

Alignment Connections

(Adapted from reference Architectural Precast Concrete, Second Edition, PCI. Used with permission Precast/Prestressed Concrete Institute in Design Guide 22.)

70

Panelized Façade Systems

Column-Supported Story-Tall Panels

Column
 Story-Tall Precast Panel
 Spandrel Beam Not Shown for Clarity

NOTES:

- ① Shim stack (or leveling bolt) bearing support at panel joint. Joint to allow differential vertical movement.
- ② Steel bracket bearing connection. Typically designed by the SSE.
- ③ Tie-back connection at top of lower panel to allow vertical and horizontal relative movement.
- ④ Stiffener plates (as required). Consider impact of stiffeners on the out-of-plane spandrel beam connection.
- ⑤ Maximum allowable eccentricity (e) specified by the Structural Engineer of Record.

71

Panelized Façade Systems

Spandrel-Supported Panels

Upper Story-Tall Precast Panel
 Upper Story-Tall Precast Panel
 Detail at Composite Deck Floor Slab


NOTES:

- ① Blockout in slab for bearing connection.
- ② Bearing clip and connection to precast is typically specified by the SSE. Connection to panel is designed for moment to resolve eccentricity (e).
- ③ Panel joint allows relative movement between panels.
- ④ Slotted (or threaded) insert tie-back connection allows vertical and in-plane relative movement.
- ⑤ Steel shape hanger from spandrel to receive tie-back connection.
- ⑥ Steel shape kicker to resist tie-back alone and avoid torsion on spandrel.
- ⑦ Stiffener plates, if required, for local flange bending for bearing clip on hanger.

72

Panelized Façade Systems

Spandrel-Supported Panels



Top of Roofing



73

Panelized Façade Systems

Potential Problems

- Erection sequence may be complex when coordinating brackets, blockouts or recesses, and embedment plates.
- Cantilever brackets on panels without sufficient stiffness may deflect or rotate significantly during erection.
- Division of responsibilities for designing and providing attachment and support components may be unclear.



74

Panelized Façade Systems

Potential Problems

- Joints in architectural elevations are not coordinated with the points of load application to the primary structure as anticipated by the SER.
- Inadequate coordination and accommodation for adjustability results in greater eccentricities than anticipated by the SER, SSE, or both.



75

Panelized Façade Systems

Potential Problems

- Attachments designed by the SSE may inadvertently:
 - Deliver moments or otherwise load the primary structure with eccentric loads not anticipated by the SER designing the primary structure.
 - Resolve horizontal and vertical kicker loads to lightweight roof elements that are not designed for the kicker loads.
 - Apply loads to the bottom flange of the spandrel.



76

Aluminum Curtain Wall Systems

Aluminum Curtain Walls



Often the most important part of the aluminum curtain wall design is anchorage adjustability to the base building structure.




77

Aluminum Curtain Wall Systems

General Description

"STICK BUILT"




78

Aluminum Curtain Wall Systems

General Description

"UNITIZED"




79

Aluminum Curtain Wall Systems

General Description

"UNIT AND MULLION"



80



Aluminum Curtain Wall Systems

Strategies for Support


- Easily accessible attachments
- Adjustability
- Limit eccentricity
- Block-outs of fire proofing
- Factory drilled bolt holes in curtain wall
- Field-welded connections



81

Aluminum Curtain Wall Systems

Strategies for Support



Dead + Lateral Attachment

Lateral Attachment

Roof

Intermediate Floor

NOTES:

- 1) Dead load attachment. Curtain wall hangs from roof structure in this example. Attachment detail needs to provide vertical and horizontal adjustments.
- 2) Wind load attachment. Detail provides out-of-plane support of mullion and allows vertical movement relative to structure.



82

Aluminum Curtain Wall Systems

Architectural Parameters

- Location of mullions
- Joints
- System type
- Story height
- Acceptable mullion size
- Direction of span



83

Aluminum Curtain Wall Systems

Accommodating Thermal Movements


- Critical to performance
- Aluminum: $\alpha_{Al} \approx 13 \times 10^{-6}$ in/in/°F
- Steel: $\alpha_S \approx 6.5 \times 10^{-6}$ in/in/°F
- Concrete: $\alpha_C \approx 5.4 \times 10^{-6}$ in/in/°F
- Façade temperatures may be 4 times the interior temperature



84

Aluminum Curtain Wall Systems

Accommodating Structural Movements




- Out-of-Plane:
 - L/175 for curtain wall
 - L/360 for members also supporting brittle finishes
 - Max. of 3/4 in.
- In-Plane:
 - L/360 common but may vary



85

Aluminum Curtain Wall Systems


Field Adjustability – Gravity Anchor




86

Aluminum Curtain Wall Systems


Field Adjustability – Lateral Anchor




87

Aluminum Curtain Wall Systems

Attachment to Spandrel Beam




88

Aluminum Curtain Wall Systems

Attachment to Spandrel Beam

Deck Orientation Varies-See Plan.

6" 1" Clr.

Bay Window (See Arch. Dwgs.)

1/2" Plate x Half Depth of Beam @ 5'-0" O.c.

Full Depth Stiff. Plate

Spandrel Beam

1" Clr.

L8x6x1/2 LLH Cont. (Coord. Attachment Detail with Window Manufacturer).



89

Aluminum Curtain Wall Systems

Attachment to Spandrel Beam

PLATE WELDED TO BACK OF ANGLE AFTER WALL ALIGNMENT

FLOOR SLAB

ANGLE TEMPORARILY ATTACHED TO BEAM WEB BY BOLTING THRU PRE-DRILLED HOLES, BY STUD BOLTS, OR BY RAMSET.

ANGLE HEEL WELDED TO BEAM WEB AFTER ALIGNMENT

EXTRUDED ANCHOR STEM

SPANDREL BEAM

ALUMINUM MULLION

(FIREPROOFING OF SPANDREL BEAM NOT SHOWN)

Movable anchor attached to face of spandrel beam



90

Aluminum Curtain Wall Systems

Attachment to Top of Slab

ANCHOR PLATE WELDED TO ANGLE AFTER ALIGNMENT

ANGLE

SHOP FABRICATED PLATE & REBAR ASSEMBLY WELDED TO DECKING, FLUSH WITH SLAB SURFACE, BEFORE POURING CONCRETE

FILLET WELDS

EXTRUDED ANCHOR STEM

ALUMINUM MULLION

SLAB EDGE

REBAR IN DECKING

STEEL FLR DECKING

Movable anchor located on top of floor slab



91

Aluminum Curtain Wall Systems

Attachment to Top of Slab

UPPER MULLION SLIPPED DOWN OVER SPICE, WITH NO FIXED ATTACHMENT

POCKET CAST IN SLAB GROUTED BY GEN'L CONTRACTOR AFTER MULLION IS IN PLACE

HEX. HD. BOLT INTO CONC. INSERT

NOTE: FOR HIGH WIND LOAD USE 2 BOLTS 4' O.C.

WELD WASHER AFTER FINAL ALIGNMENT

EXTRUDED COMBINATION ANCHOR & SPICE

SHEET METAL CLOSURE TO METAL DECKING

MULLION SPICE SHOP ATTACHED & SEALED TO LOWER MULLION SECTION

FIXED anchor for top of mullion, movable anchor for bottom of mullion above, located in pocket cast in top of floor slab



92

Aluminum Curtain Wall Systems

Attachment to Top of Slab

Fixed anchor for top of mullion, movable anchor for bottom of mullion above, located on top of floor slab



93

Aluminum Curtain Wall Systems

Potential Problems

- Large gaps between the anchors and the primary building structure can result in excessive bending stresses.
- Coordination of locations for adjustment.
- Slotted holes must be long enough to accommodate adjustment.



94

Aluminum Curtain Wall Systems

Potential Problems

- Coordination of bolted attachments to the primary building structure.
- Mullion splices should properly account for volume changes and movement of the primary building structure.



95

Sizing Joints for Vertical Movement

Sizing Joints for Vertical Movement



Facade joints are building components just like mechanical or structural components and need to be explicitly **designed**.



96

Sizing Joints for Vertical Movement

Joint Fundamentals

- Joints are necessary in facades.
- Joints accommodate movement and tolerances.
- Joints control air and water - especially in barrier systems.

Labels in diagram: Backer Rod, Sealant, 1/2", Face of Facade.

97

Sizing Joints for Vertical Movement

Movement Types

- Dead (Self) Load
- Superimposed Dead Load
- Live Load
- Snow/Rain Load
- Wind Load Drifts
- Seismic (Earthquake) Drifts
- Long-Term Shrinkage
- Differential Settlement
- Thermal Movements
- Moisture Movements

98

Sizing Joints for Vertical Movement

Joint Movements

- Dead Load (Self-Weight) Deflections
- Superimposed Dead Load Deflections
- Facade Weight Deflections

Pre-Service Superstructure Movements → **DO NOT*** need to be considered in the facade joint design.

Superstructure Movements during Facade Installation → **MIGHT** need to be considered in the facade joint design, depending on the facade type and its ability to be adjusted after installation.

Labels in diagrams: Facade Outboard of Slabs, Vertical adjustment not possible.

99

Sizing Joints for Vertical Movement

Joint Movements

- Live Load Deflections
- Snow/Rain Load Deflections
- Wind Load Deflections/Drift
- Seismic Deflections/Drift
- Long-Term Shrinkage
- Differential Settlement
- Thermal Movements
- Moisture Movements

In-Service Superstructure Movements → **MUST** be considered in the facade joint design.

In-Service Facade Movements → **MUST** be considered in the facade joint design.

100

Sizing Joints for Vertical Movement

Vertical Joint Movements Façade Loads

- Weight of façade causes spandrel beam to deflect vertically
- Spandrel beam may twist under weight of façade at slab edge
- Twisting motion translates to additional façade joint closure

101

Sizing Joints for Vertical Movement

Vertical Joint Movements Live, Snow, and Rain Loads

102

Sizing Joints for Vertical Movement

Vertical Joint Movements Live, Snow, and Rain Loads

Potential “pinch points” include:

- Floors with different design live loads
- Unloaded floor beneath loaded floor
- Floor level immediately below the roof
- First level above foundation wall/base of façade

103

Sizing Joints for Vertical Movement

Vertical Joint Movement Creep and Column Shortening


- Creep deformations over time in concrete buildings
- Column shortening in tall buildings, particularly at lower floors

104

Sizing Joints for Vertical Movement

Facade Movements Moisture Changes

- Most relevant for masonry and stone
- Brick masonry expands irreversibly due to water absorption by 0.02 – 0.07%.




The diagram shows a brick wall with blue arrows indicating expansion in all directions (up, down, left, right). A label 'Direction of Expansion' points to these arrows. To the right is a photograph of a brick building facade with windows.

109

Sizing Joints for Vertical Movement

Joint Types: Sealant

- Medium Modulus Silicone Sealant
 - +50% / -50% typical movement capacity
 - Not all sealant has the same movement capacity
 - Need to confirm with manufacturer's product data




The diagram shows a 3D perspective of a sealant joint between two surfaces. Yellow arrows indicate longitudinal shear, green arrows indicate transverse shear, red arrows indicate tension, and blue arrows indicate compression.

110

Sizing Joints for Vertical Movement

Joint Types: Extruded Silicone Sheet

- Typical Capacities
- +200% capacity
- -75% capacity




The diagram shows a cross-section of a window joint. Labels include: 'HEAD', 'SILL', 'ExoAir Sheet', 'Proglaze ETA Off-Set Dart', and 'Extruded Aluminum'. To the left are three photographs showing the extruded silicone sheet in different configurations.

111

Sizing Joints for Vertical Movement

Joint Types: Extruded Silicone Sheet



The photograph shows a window with red circles highlighting the joint area. To the right is a detailed cross-section diagram of the window assembly, showing the 'MEMBRANE', 'SILL', 'HEAD', and 'SPANDREL GLASS'. Dimensions are provided, including a width of 6 3/4" for the spandrel glass.

112

Sizing Joints for Vertical Movement

Load Combinations for Joint Design

- The building code provides some guidance on load combinations, but no specific requirements.
- Serviceability checks may allow lower forces and drifts; for example joint sealant movements.
- ASCE 7-16 Commentary suggests:

$$D + 0.5L + W_a$$




113

Sizing Joints for Vertical Movement

Sizing Horizontal Façade Joints

$$J = \frac{\alpha \Delta_T h + k_e h + \delta_{sil}}{M} + Tol + \delta_{ps}$$

- α = coeff. thermal exp.
- k_e = coeff. Moisture exp.
- Δ_T = design temp. change
- h = vertical spacing between joints
- δ_{sil} = deflection after sealant is installed
- M = compressibility of sealant material
- Tol = allowance for tolerance
- δ_{ps} = deflection prior to sealant installation



114

Sizing Joints for Vertical Movement

Example 7.1: Determination of Deflections for Structures Supporting Brick Veneers


For the clay brick veneer on a building supported at each floor level by a shelf angle, determine the amount by which the brick will expand and the amount by which the spandrel beam can deflect before compressing the joint filler material to its maximum allowable compressibility.



115

Sizing Joints for Vertical Movement

Example 7.1




116

Sizing Joints for Vertical Movement

Example 7.1

Given:
 The brick height between the shelf angles, $h = 14$ ft. The vertical as-built construction tolerance of the building, $Tol = 1/8$ in. The shelf angle deflection under the weight of the brick with respect to the floor below, $\delta_a = 1/16$ in.

The brick veneer is installed at an ambient temperature of 40 °F. The exterior wall of the building may experience a change in temperature, $\Delta_T = 100$ °F. The brick coefficient of thermal expansion, $\alpha = 4 \times 10^{-6}$ in./in./°F, and the brick coefficient of moisture expansion, $k_e = 3 \times 10^{-4}$ in./in.

The largest design gap width before sealant installation, $J' = 7/8$ in. The joint filler material is a high-performance sealant and the compressibility of the sealant material, $M = 50\%$.




117

Sizing Joints for Vertical Movement

Example 7.1

Step 1: Determine the amount by which the brick will expand.

Width of sealant joint	$J = 0.875$ in.
Compressibility of sealant material	$M = 50\%$
Anticipated construction vertical tolerance	$Tol = 0.125$ in.
Shelf angle deflection	$\delta_a = 0.0625$ in.
Brick coefficient of thermal expansion	$\alpha = 4(10^{-6})$ in./in./°F
Brick coefficient of moisture expansion	$k_e = 3(10^{-4})$ in./in.
Height of brick between shelf angles	$h = 14$ ft
Change in temperature	$\Delta_T = 100$ °F





118

Sizing Joints for Vertical Movement

Example 7.1

The design gap before sealant is installed with may be expressed by the following equation:



$$J' = J + Tol + \delta_{ps}$$

$$J' = \frac{\alpha \cdot \Delta_T \cdot h + k_e \cdot h + \delta_{sil}}{M} + Tol + \delta_{ps}$$

$$\delta_{sil} + M\delta_{ps} = M(J' - Tol) - (\alpha\Delta_T h + k_e h)$$

$$\delta_s = \delta_{sil} + M\delta_{ps}$$

$$\delta_{vb} = k_e h + \alpha\Delta_T h$$

Note that the shelf angle deflection includes deflection of the horizontal leg of the angle as well as the deflection of the shelf angle between attachments to the building structure.




119

Sizing Joints for Vertical Movement

Example 7.1

The volume change of the brick between the shelf angles is,



$$\delta_{vb} = k_e h + \alpha\Delta_T h$$

$$= (3 \times 10^{-4} \text{ in./in.})(14 \text{ ft})(12 \text{ in./ft})$$

$$+ (4 \times 10^{-6} \text{ in./in./°F})(100 \text{ °F})(14 \text{ ft})(12 \text{ in./ft})$$

$$= 0.118 \text{ in.}$$


120


Sizing Joints for Vertical Movement

Example 7.1

The amount of movement that the joint can accommodate is,

$$\begin{aligned}\delta_{jm} &= M(J' - Tol) \\ &= 0.50\left(\frac{7}{8} \text{ in.} - \frac{1}{8} \text{ in.}\right) \\ &= 0.375 \text{ in.}\end{aligned}$$

Thus, the permissible structural deflection, including the deflection due to the loads applied prior to installation of the sealant joint is,

$$\begin{aligned}\delta_s &= \delta_{jm} - \delta_{vb} \\ &= 0.375 \text{ in.} - 0.118 \text{ in.} \\ &= 0.257 \text{ in.}\end{aligned}$$



121

Sizing Joints for Vertical Movement

Example 7.1


The total structural deflection is $\delta_{sil} + M\delta_{ps}$, where

$$\delta_{ps} = \delta'_{sb} + \delta_s$$

The deflection of the spandrel beam, δ'_{sb} , due to the brick load and δ_s is the total deflection of the shelf angle due to the brick load. Substituting this quantity back into the equation for the total structural deflection, and limiting the total to not exceed δ_s ,

$$\delta_{sil} + M\delta'_{sb} + M\delta_s \leq \delta_s$$

The deflection of the spandrel beam is proportional to the load on it. Knowing that the uniformly distributed load due to the brick on the spandrel is w_{sb} , and the superimposed load is w_{sil} , the deflection of the spandrel beam due to the uniformly distributed load due to the brick is,

$$\delta'_{sb} = \delta_{sil} \frac{w_{sb}}{w_{sil}}$$



122


Sizing Joints for Vertical Movement

Example 7.1

This ratio assumes that the interior beams are parallel to the spandrel beam and do not frame into the spandrel beam. The assumption may still be a reasonable approximation when floor beams frame to the spandrel beam. Substituting this relationship back into the equation for δ_s above gives,

$$\delta_{sil} + M\left(\delta_{sil} \frac{w_{sb}}{w_{sil}}\right) + M\delta_s \leq \delta_s$$

Rearranging this for δ_{sil} , the amount the spandrel beam can deflect is,

$$\begin{aligned}\delta_{sil} &\leq \frac{\delta_s - M\delta_s}{1 + M\left(\frac{w_{sb}}{w_{sil}}\right)} \\ &\leq \frac{0.257 \text{ in.} - 0.50\left(\frac{1}{16} \text{ in.}\right)}{1 + 0.50(1)} \\ &\leq 0.151 \text{ in.}\end{aligned}$$



123


Sizing Joints for Vertical Movement

Example 7.1

This calculation requires the designer to make assumptions about the brick and superimposed loads on the beam, which may be difficult during preliminary design. In practice, it is conservative and often easier to use the total of the brick deflection and the superimposed load deflection such that:

$$\delta_s = \delta_{ps} + \delta_{sil}$$

Note that at the first elevated floor level where the brick below the shelf angle is supported on a foundation wall, δ_{ps} may be significant. At upper floor levels, however, where the spandrel beam on the floor below the shelf angle may deflect approximately as much as the spandrel beam supporting the shelf angle in question, δ_{ps} may be small. Thus, one can often conservatively select a beam for which the total deflection associated with cladding loads, superimposed dead loads, and live loads is less than δ_s .




124

Sizing Joints for Vertical Movement

Effects of Vertical Movements on Vertical Joints

Vertical Movements

Effect on horizontal joint due to vertical movement.

Effect on vertical joint due to vertical movement.

Undeformed

Deformed

Undeformed



125

Sizing Joints for Vertical Movement

Effects of Horizontal Movements on Vertical Joints

Horizontal Movements

Effect on horizontal joint due to horizontal movement.

Effect on vertical joint due to horizontal movement.

interlock corner panel

Undeformed

Deformed

Undeformed



126

AISC | Questions?



**Smarter.
Stronger.
Steel.**

Single-Session Registrants

CEU / PDH Certificates

- You will receive an email on how to report attendance from: registration@aisc.org.
- Be on the lookout: Check your spam filter! Check your junk folder!
- Completely fill out online form. Don't forget to check the boxes next to each attendee's name!



**Smarter.
Stronger.
Steel.**

Single-Session Registrants

CEU / PDH Certificates

- Reporting site (URL will be provided in the forthcoming email).
- Username: Same as AISC website username.
- Password: Same as AISC website password.



4-Session Registrants

CEU / PDH Certificates

One certificate will be issued at the conclusion of the course.



4-Session Registrants

Attendance and PDH Certificates

- For Session R1, you must pass the quiz to receive credit for the session.
- For Sessions L1 – L3, you have two options to receive credit for the session.
 - Option 1: Watch the live session. Credit for live attendance will be displayed on the Course Resources table within two days of the session.
 - Option 2: Watch the recording and pass the associated quiz.

Videos and Quizzes

- Session R1 video recording and quiz access has been available since you registered.
- For Sessions L1 – L3, find access by the end of the day, Friday, after the live air date. (An email will be sent from webinars@aisc.org.)
- All video recordings and quizzes are available until 8:00 a.m. ET on June 17.
- Quiz scores are displayed in the Course Resources table.

Distribution of Certificates

All certificates will be issued after the course is completed (the week of June 17). Only the registrant will receive a certificate for the course.



4-Session Registrants

Course Resources

Find all your handouts, quizzes and quiz scores, recording access, and attendance information in one place!



4-Session Registrants

Course Resources

Go to www.aisc.org and sign in.

The screenshot shows the AISC website's login page. At the top, there is a navigation menu with links for EDUCATION, PUBLICATIONS, STEEL SOLUTIONS CENTER, AWARDS AND COMPETITIONS, and TECHNICAL RESOURCES. Below the menu is a large image of a modern building with a glass facade. The AISC logo is visible in the top left corner. The main content area contains a login form with fields for USERNAME and PASSWORD, a "Remember Me" checkbox, and a "LOGIN" button. To the right of the form, there is a "DON'T HAVE AN ACCOUNT?" section with a "REGISTER NOW" button. At the bottom of the form, there are links for "Forgot Username?" and "Forgot Password?".

4-Session Registrants

Course Resources

Go to www.aisc.org and sign in.

The screenshot shows the MyAISC user profile page. On the left, there is a sidebar menu with links for "Edit Profile", "My Downloads", "My Pending Quizzes", "My Events", "Order History", "Course History", and "Course Resources". The "Course Resources" link is circled in red. The main content area is titled "MyAISC" and includes sections for "MY PROFILE" (with an "EDIT PROFILE" button), "MY PURCHASED DOWNLOADS" (with a "VIEW DOWNLOADS" button), and "MY COURSE RESOURCES" (with a "VIEW RESOURCES" button). The "MY COURSE RESOURCES" section is also circled in red.

4-Session Registrants

Course Resources

The screenshot shows the "Course Resources" page. At the top, there is a navigation menu with links for EDUCATION, PUBLICATIONS, AWARDS AND COMPETITIONS, TECHNICAL RESOURCES, and STEEL SOLUTIONS CENTER. Below the menu is a large image of a modern building with a glass facade. The AISC logo is visible in the top left corner. The main content area is titled "Course Resources" and contains a table of events.

Event	Start Date
Session Overview on Steel	1/15/2010 12:00:00 AM
4-Session Package: Design of Façade Attachments	5/9/2019 1:00:00 PM
101-20-8-Session Package-Foreign School 18 - Fundamentals of Corrosion Design	10/5/2017 7:00:00 PM
101-20-8-Session Package-Foreign School 18 - Session: Design on Steel	1/5/2019 7:00:00 PM
101-20-8-Session Package-Foreign School 11: Design of Façade Attachments	7/6/2018 7:00:00 PM
101-20-8-Session Package-Foreign School 18: Steel Construction: High-Temperature Out	10/15/2018 7:00:00 PM
101-20-8-Session Package-Foreign School 18: Connection Details	1/4/2019 7:00:00 PM
101-20-8-Session Package-Foreign School 20: Classical Methods of Structural Analysis	6/5/2019 7:00:00 PM
8-Session Package-Session Design on Steel - Concrete & Steel	7/18/2018 1:00:00 PM

4-Session Registrants

Course Resources

The screenshot shows the "Design of Façade Attachments 4-Session Package Resources" page. At the top, there is a navigation menu with links for EDUCATION, PUBLICATIONS, AWARDS AND COMPETITIONS, TECHNICAL RESOURCES, and STEEL SOLUTIONS CENTER. Below the menu is a large image of a modern building with a glass facade. The AISC logo is visible in the top left corner. The main content area is titled "Design of Façade Attachments" and contains a section for "4-SESSION PACKAGE RESOURCES" with a table of events.

Event	Date	Platform	Video	Quiz	Attendance
R1: Façade Fundamentals	N/A	Standards	30:00	Pass/Fail	N/A
L1: Façade Attachments Part 1	May 9 2019 1:00PM EDT	Standards	Available 05/11/2019 5:00PM EDT	Available 05/11/2019 5:00 PM EDT	Pending
L2: Façade Attachments Part 2	May 10 2019 1:00PM EDT	Standards	Available 05/13/2019 5:00PM EDT	Available 05/13/2019 5:00 PM EDT	Pending
L3: Façade Attachments - Building Lateral Drifts	May 23 2019 1:00PM EDT	Standards	Available 05/25/2019 5:00PM EDT	Available 05/25/2019 5:00 PM EDT	Pending
Total Exam	N/A			Available 5/27/2019 5:00 PM EDT	



